ACTIVA PRODUCTS INC. INSTAMOLD MIXING CHART (MEASURE BY VOLUME)

	THICK STRONG MIX	<i>MEDIUM</i> AVERAGE MIX
MIXING	1 PART INSTAMOLD	1 PART INSTAMOLD
PROPORTIONS	2 PARTS WATER	3 PARTS WATER
	a) Greater volume of	a) Cractagt total
CHARACTER-	mix	a) Greatest total volume of mix
ISTICS	b) Slower settingc) Average	b) SLOWEST setting
	retention	c) less-accurate shape retention
	of shape and size	d) Should be
	d)Withstands average	handled
	handling e) Retains fine detail	more carefully e) Retains fine detail
Setting Time		
at 70 F	4 - 6 Minutes	8 - 12 Minutes
		When you need a
When to use	General use	bigger batch for a large model and you
		more time in which to
		Work . Undercuts
		may tear fine detail
		away,
		unless care is used

NOTE: One average package if INSTAMOLD (12ounces, by WEIGHT) contains a VOLUME of about

40 ounces. This will mix with 40 - 120 ounces of water